


Universal Relay & Snubber



The Warmup Universal relay will interface with most thermostats.

The snubber unit should be connected across the coil of the relay, to suppress any spikes that may be created.

Connection:

- Red & Black wires should be connected to the load terminals of the thermostat.
- Red wire – to the Phase supply
- Red wire to the heating element.